

CHEVRONS

& Chapter 8 Markings



Installation Guide - Chevron Kits

Guide for Wet Installation Films

Checking the Kit

- Open the packaging and inspect the kit for any transit damage.
- Check that it is the correct kit for the vehicle and that all of the components are there and that they fit the vehicle.
- If you have any queries please raise them at this stage, do not begin to fit a partial kit.

Preparing the Vehicle

- Remove any badges using Metamark Adhesive Remover to remove any glue.
- Clean the area of the vehicle required with Metamark Surface Cleaner and a microfibre or lint free cloth.
- After washing, degrease the area with Metamark Isopropyl Alcohol (IPA). Do not use white spirits.
- Ensure the vehicle is under cover and that the ambient temperature is greater than 5°C, but preferably around 15-20°C. Do not apply in extremely cold conditions.

CHEVRONS »

& Chapter 8 Markings



Application

- For Fluorescent Yellows, firstly unroll the sheet with the yellows attached and fix it to the side of the vehicle using either magnets or masking tape.
- Starting with the largest piece, extract it from the sheet whilst spraying it with Metamark Application Fluid.
- Line the piece up on the panel it is to fit, starting on the inside edge of the door, leaving about a 5mm gap to the edge.
- Once in position, apply pressure with a squeegee to remove the excess solution. Take care not to leave any bubbles or creases by using long overlapping vertical strokes.
- Repeat the above steps for the other panels.
- Once the kit has been applied, remove any lifting edges by applying the squeegee once again. If necessary, heat the area gently using a heat gun on low setting and again apply the squeegee.
- For Reflective Reds, unroll the sheet with the reds attached and fix to the side of the van using magnets or masking tape.
- Match each piece to the yellow panels using the instructions provided.
- When applying the reds, apply in exactly the same way as the yellow panels. Take time to line them up correctly.

Tips and Tricks

- Make sure you use a mild detergent and clean water on the van before fitting any chevrons.
- Check the full kit before fitting!
- Install wet for ease of application.
- Don't use solvents, abrasives or alcohol based cleaners.
- Don't use a jet wash close to the livery or on the chevrons.

Tools Required for Installation

Following the Installation Guide, tools required include the following:

- Metamark Adhesive Remover
- Metamark Surface Cleaner
- Metamark Isopropyl Alcohol
- Metamark Application Fluid
- Spray Bottle
- Squeegee
- Masking Tape
- Magnets
- Kraft Knife
- Stanley Blade
- Microfibre or Lint Free Cloth

All products are available from Metamark.

Follow all the stages in order to apply your Chevron kit. If any issues arise, please do not hesitate to contact us. For technical support email chevrns@metamark.co.uk or call +44 (0)1483 571111