

Follow all the stages in order to apply your Chevron kit. If any issues arise, please do not hesitate to contact us.



Stage 1 - Checking your Kit

- Open the packaging and inspect the kit for any transit damage.
- Check that it is the correct kit for the vehicle and that all of the components are there and that they fit the vehicle.
- If you have any queries please raise them at this stage, do not begin to fit a partial kit.

Stage 2 - Preparing the Vehicle

- Remove any badges using Metamark Adhesive Remover to remove any glue.
- Clean the area of the vehicle required with Metamark Surface Cleaner and a microfibre or lint free cloth.
- After washing, degrease the area with Metamark Isopropyl Alcohol (IPA). Do not use white spirits.
- Ensure the vehicle is under cover and that the ambient temperature is greater than 5°C, but preferably around 15-20°C. Do not apply in extremely cold conditions.

Stage 3 - Application

- For Fluorescent Yellows, firstly unroll the sheet with the yellows attached and fix it to the side of the vehicle using either magnets or masking tape.
- Starting with the largest piece, extract it from the sheet whilst spraying it with Metamark Application Fluid.
- Line the piece up on the panel it is to fit, starting on the inside edge of the door, leaving about a 5mm gap to the edge.
- Once in position, apply pressure with a squeegee to remove the excess solution. Take care not to leave any bubbles or creases by using long overlapping vertical strokes.
- Repeat the above steps for the other panels.
- Once the kit has been applied, remove any lifting edges by applying the squeegee once again. If necessary, heat the area gently using a heat gun on low setting and again apply the squeegee.
- For Reflective Reds, unroll the sheet with the reds attached and fix to the side of the van using magnets or masking tape.
- Match each piece to the yellow panels using the instructions provided.
- When applying the reds, apply in exactly the same way as the yellow panels. Take time to line them up correctly.

For further technical support email chevrons@metamark.co.uk or call +44 (0)1483 571111



Tips and Tricks!

- Make sure you use a mild detergent and clean water on the van before fitting any chevrons.
- Check the full kit before fitting!
- Install wet for ease of application.
- Don't use solvents, abrasives or alcohol based cleaners.
- Don't use a jet wash close to the livery or on the chevrons.

Make sure you have:

- Metamark Adhesive Remover
- Metamark Surface Cleaner
- Metamark Isopropyl Alcohol
- Metamark Application Fluid
- Squeegee
- Spray Bottle
- Masking Tape
- Magnets
- Kraft Knife
- Stanley Blade
- Microfibre or Lint Free Cloth

All products are available from Metamark.

For further technical support email chevrons@metamark.co.uk or call +44 (0)1483 571111