

Materials Required;

Warm soapy water
Bottle 1 - Metamark Adhesive Remover
Bottle 2 - Metamark Surface Cleaner
Bottle 3 - 100% isopropanol or preferred final cleaning product
Cloth /paper towel - lint free
Towel - Micro fibre
DO NOT USE BLUE ROLL

Pre-Installation;

Vehicle delivered prior to installation to acclimatise. E.g. afternoon before install.
If a new vehicle, request PDI (Pre-Delivery Inspection) do not use wax silicones.
If customer cleans request no wax, silicones.
Steam clean panel/s, vinyl is to be applied to.

Cleaning;

Step 1 - Remove any standing dirt and grime with warm soapy water.
Step 2 - Allow to dry / dry with towel
Step 3 - Use BOTTLE 1 to remove Traffic Film / Wax Silicones.
Step 4 - Use BOTTLE 2- To clean off any BOTTLE 1 residue
Step 5 - Use BOTTLE 3 – Final Clean.

Particular care should be paid to recesses, indents and edges.
Change cloth and turn regularly. Do not cross contaminate cloths.
Make sure installer does final cleaning and make sure THEY are happy.

MetaTip:

After final clean, apply heat around recesses, indents & edges to burn off any liquid residue/particals that may remain.

For further technical support email technical@metamark.co.uk or call +44 (0)1483 571111

Metamark (UK) Limited

Luneside • New Quay Road • Lancaster • LA1 5QP • Tel +44 (0)1524 387140 • Fax +44 (0)1524 387147
Metamark House • Octimum Business Park • Forsyth Road • Woking • GU21 5SF • Tel +44 (0)1483 571111 • Fax +44 (0)1483 570540

sales@metamark.co.uk
www.metamark.co.uk