

# Onyx 6.5

## Metamark Profiles Installation

The following instructions describe how to import Metamark media OML profiles into the RIP. If you need any further assistance please contact the sales office on 0845 345 5645:

1. Insert Profile CD
2. With Onyx 6.5 open, click on Media Manager.
3. Using media manager, click the All Profiles tab.
4. Click on the Media tab on the top and select Import.
5. In the now window open window change the Files Of Type to search for OML files and open the disk drive and select the OML file you wish to import.
6. The Import Media window will now open, tick the Profile you wish to import and press the Import Button.
7. You will now be able to add use this profile within Onyx 6.5.
8. To add more profiles repeat 1 – 7.